

Programming Guide

Advanced 2D Image Scanner

This Programming Guide is intended for:

- 2D Image Hands-Free Scanner: Z-6012GT

Revision History

Changes to the original manual are listed below:

Version	Date	Description of Version
1.0	2023-10-6	Initial release

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for any particular purpose. We are not liable for any errors contained herein nor for incidental or consequential damages in connection with furnishing, performance or use of this material. We shall be under no liability in respect of any defect arising from fair wear and tear, willful damage, negligence, abnormal working conditions, failure to follow the instructions and warnings, or misuse or alteration or repair of the products without written approval. No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any human or computer or other language in any form or by any means electronic, mechanical, magnetic, optical, chemical, biological, manual or otherwise, except for brief passages which may be quoted for purposes of scholastic or literary review, without express written consent and authorization. We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. All trademarks mentioned herein, registered or otherwise, are the properties of their various, ill, assorted owners.

General Handling Precautions

Do not dispose the scanner in fire.
Do not put the scanner directly in the sun or by any heat source.
Do not use or store the scanner in a very humid place.
Do not drop the scanner or allow it to collide violently with other objects.
Do not take the scanner apart without authorization

Guidance for Printing

This manual is in A5 size. Please double check your printer setting before printing it out. When the barcodes are to be printed out for programming, the use of a high-resolution laser printer is strongly suggested for the best scan result.

Firmware Notice

To use all functions in this guide please update to the latest firmware.

Copyright © 2024 ZEBEX INDUSTRIES INC. All rights reserved.

Table of Contents

Important Notice.....	ii
General Handling Precautions.....	ii
Guidance for Printing.....	ii
Default Parameters.....	1
Factory Default Setting.....	1
Using the Scanner.....	3
Beeper Indication.....	3
LED Indication.....	3
Settings and Programming.....	4
Program Set Up Flow.....	4
User Preferences.....	5
Show Version.....	5
System Settings.....	5
Customer's Factory Default.....	6
Scan Mode.....	7
Standby Time.....	9
Same Code Delay Time for Continue Mode.....	11
Decode Time.....	12
Customization Gain Level.....	13
Motion Detect Sensibility for Auto Scan Mode & Presentation Mode.....	15
Idle Wake Sensibility Level.....	17
Illumination LED Behavior.....	19
Decoded Illumination LED Behavior for Kiosk Mode.....	20
Decoded delay time for Auto Scan Mode.....	21
Mobile Phone Scan Support.....	22
Power Up Beep On/ Off.....	23
Good Read Beep On/ Off.....	24
Good Read Beep Length.....	25
Interface Switch.....	26
Terminal Character.....	27
RS232 Baud Rate.....	28
RS232 Parity Bit.....	30
RS232 Stop Bit.....	31
RS232 Data Bit.....	32
USB Speed.....	33
USB Output Speed for USB 1.1.....	34
Country Code.....	37
Persian/Arabic Language Encoding Support.....	43
Readable Symbolologies.....	44
All Symbolologies.....	44

UPC-A45

UPC-E.....46

EAN-847

EAN 13.....48

JAN code for Books.....49

Code 12850

Code 3951

Code 9352

Code 3253

Code 1154

Codabar.....55

Plessey.....56

MSI/Plessey.....57

Interleaved 2 of 558

IATA 2 of 559

Matrix 2 of 560

Straight 2 of 561

RSS 14 (GS1 DATABAR 14)62

RSS Expanded (GS1 DATABAR Expanded).....63

RSS Limited (GS1 DATABAR Limited).....64

Component CC-A.....65

Component CC-B.....66

Component CC-C.....67

PDF41768

Micro PDF417.....69

Data Matrix70

QR Code71

Micro QR Code72

GS1-2D AIM ID73

GS1-128 AIM ID.....74

GS1 DataBar Expanded Stacked75

GS1 DataBar 14 Stacked76

Aztec.....77

Pharmacode78

MaxiCode79

Symbology Features80

 UPC / EAN.....80

 UPC-A81

 UPC-A Data Redundant Check.....83

 UPC-E.....84

 EAN 8.....86

 EAN 8 Data Redundant Check87

EAN 13.....	88
EAN 13 Data Redundant Check	91
JAN code for Books Separator	92
Code 39	94
Code 39 Data Redundant Check.....	96
Codabar	97
Codabar Redundant Check.....	99
Code 93 Data Redundant Check.....	100
Code 128 Redundant Check	101
Interleaved 2 of 5	102
Interleaved 2 of 5 Data Redundant Check.....	104
MSI / Plessey	105
Code 11	107
Data Matrix	108
QR / Micro QR	109
Japanese Language Encoding Support	111
Aztec.....	112
FNC1 GS Substitution Values.....	113
Code 32 (Italian Pharmacode).....	114
PDF-417 Data Redundant Check	115
Matrix 2 of 5.....	116
Straight 2 of 5.....	117
Data Editing (Prefix)	118
Prefix Set Up Flow	118
All Prefix	119
UPC / EAN Prefix.....	120
Code 128 Prefix	122
Code 39 Prefix	123
Code 93 Prefix	124
Code 32 Prefix	125
Code 11 Prefix	126
Codabar Prefix.....	127
Plessey Prefix.....	128
MSI Prefix	129
Interleaved 2 of 5Prefix	130
IATA 2 of 5 Prefix	131
Matrix 2 of 5 Prefix.....	132
Straight 2 of 5 Prefix.....	133
RSS 14 Prefix (GS1 DATABAR 14 Prefix)	134
RSS Expanded Prefix (GS1 DATABAR Expanded Prefix).....	135
RSS Limited Prefix (GS1 DATABAR Limited Prefix)	136
Component CC-A Prefix.....	137

Component CC-B Prefix 138

Component CC-C Prefix 139

PDF 417 Prefix 140

Micro PDF 417 Prefix 141

Data Matrix Prefix 142

QR Prefix 143

Micro QR Prefix 144

Aztec Prefix 145

MaxiCode Prefix 146

Data Editing (Suffix) 147

Suffix Set Up Flow 147

All Suffix 148

UPC-A Suffix 149

UPC-E Suffix 150

EAN 8 Suffix 151

EAN 13 Suffix 152

Code 128 Suffix 153

Code 39 Suffix 154

Code 93 Suffix 155

Code 32 Suffix 156

Code 11 Suffix 157

Codabar Suffix 158

Plessey Suffix 159

MSI Suffix 160

Interleaved 2 of 5 Suffix 161

IATA 2 of 5 Suffix 162

Matrix 2 of 5 Suffix 163

Straight 2 of 5 Suffix 164

RSS 14 Suffix (GS1 DATABAR 14 Suffix) 165

RSS Expanded Suffix (GS1 DATABAR Expanded Suffix) 166

RSS Limited Suffix (GS1 DATABAR Limited Suffix) 167

Component CC-A Suffix 168

Component CC-B Suffix 169

Component CC-C Suffix 170

PDF-417 Suffix 171

Micro PDF-417 Suffix 172

Data Matrix Suffix 173

QR Code Suffix 174

Micro QR Suffix 175

Aztec Suffix 176

MaxiCode Suffix 177

Data Editing (Truncate/Return) 178

Suffix Set Up Flow.....	178
Set All Symbologies Truncate/Return.....	179
Set UPC-A Truncate/Return.....	181
Set UPC-E Truncate/Return.....	183
Set EAN-8 Truncate/Return.....	185
Set EAN 13 Truncate/Return.....	187
Set Code 128 Truncate/Return.....	189
Set Code 39 Truncate/Return.....	191
Set Code 93 Truncate/Return.....	193
Set Code 32 Truncate/Return.....	195
Set Code 11 Truncate/Return.....	197
Set Codabar Truncate/Return.....	199
Set Plessey Truncate/Return.....	201
Set MSI (Modified Plessey) Truncate/Return.....	203
Set Interleaved 2 of 5 Truncate/Return.....	205
Interleaved 2 of 5 (ITF).ReturnLeft.4.....	207
Set IATA 2 of 5 Truncate/Return.....	208
Set Matrix 2 of 5 Truncate/Return.....	210
Set Straight 2 of 5 Truncate/Return.....	212
Set RSS 14 (GS1 DataBar) Truncate/Return.....	214
Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return.....	216
Set RSS Limited (GS1 DataBar Limited) Truncate/Return.....	218
Set Component CC-A Truncate/Return.....	220
Set Component CC-B Truncate/Return.....	222
Set Component CC-C Truncate/Return.....	224
Set PDF 417 Truncate/Return.....	226
Set Micro PDF 417 Truncate/Return.....	228
Set Data Martrix Truncate/Return.....	230
Set QR Truncate/Return.....	232
Set Micro QR Truncate/Return.....	234
Set Aztec Truncate/Return.....	236
Set MaxiCode Truncate/Return.....	238
Code Settings.....	240
Set Lengths for Codes.....	240
Set Lengths for Code 128.....	242
Set Lengths for Code 39.....	243
Set Lengths for Code 93.....	244
Set Lengths for Codabar.....	245
Set Lengths for Interleaved 2 of 5.....	246
Set Lengths for Code 11.....	247
Set Lengths for MSI.....	248
Set Lengths for Matrix 2 of 5.....	249

- Code Identifiers250
- Code Identifiers Table251
- USB Keyboard FN 1 Substitution252
- Keyboard Caps Lock State253
- Function Key Mapping255
- Function Key Extended.....256
- ASCII Code257
- USB Virtual COM Driver Installing.....281
- JavaPOS Setting282
 - JavaPOS282
 - JavaPOS Version283
 - Install the Java2 Runtime Environment.....283
 - Install the Service Object and JavaPOS files283
 - How to use RS232 scanner with JavaPOS Driver283
 - Use barcodes to configure the scanner.....284
 - Running the JavaPOS Test utility285
 - How to use JavaPOS driver at your application.....285
 - How to use USB scanner with JavaPOS Driver286
 - Install the Java RXTXcomm API287
 - Running the JavaPOS Test utility287
 - How to Use JavaPOS Driver at your application288

Default Parameters

The factory default setting table gives the default settings of all the programmable parameters. The default settings will be restored whenever the "Reset" programming label is scanned and the scanner is in programming mode. Default values are highlighted in grey background in the settings.

Factory Default Setting

Scanner Operation

User Preferences	
Parameter	Default
Baud Rate	9600 BPS
Interface	USB Keyboard
Good read beep length	50 msec
Terminal character	CR
Country code	US

Symbologies

Symbology	Default
UPC-A	Enable
UPC-E	Disable
EAN-8	Enable
EAN 13	Enable
JAN code for Books	Disable
Code 128	Enable
Code 39	Enable
Code 93	Enable
Code 32	Disable
Code 11	Disable
Codabar	Enable
Plessey	Enable
MSI/Plessey	Disable
Interleaved 2 of 5	Enable
IATA 2 of 5	Disable
Matrix 2 of 5	Disable
Straight 2 of 5	Disable
RSS 14	Enable
RSS Expanded	Enable
RSS Limited	Enable
Component CC-A	Disable
Component CC-B	Disable
Component CC-C	Disable
PDF417	Enable
Micro PDF417	Enable
Data Matrix	Enable
QR Code	Enable
Micro QR Code	Enable
GS1-2D AIM ID	Disable
GS1-128 AIM ID	Disable
GS1 DataBar Expanded Stacked	Disable
GS1 DataBar 14 Stacked	Disable
Aztec	Disable
MaxiCode	Disable

Using the Scanner

Beeper Indication

Beeps	Indication
3 beeps in a series from low to high pitch	Power up
1 short beep	A barcode has been successfully decoded
2 short beeps	The scanner has entered program mode
1 long beep	A setting has been programmed
3 beeps in a series from low to high pitch	The scanner has exited program mode
3 short beeps	Error setting the scanner

LED Indication

LED	Indication
1 Red flash	A barcode has been successfully decoded.
Steady Blue	Scanner is in work mode.
Red and blue slow interchange	Scanner is in standby.
Red and blue quick interchange	Scanner is updating.
Steady purple	Scanner is in mobile phone mode.

Settings and Programming

Scan selected barcodes in this manual to affect setup and programming of your 2D image barcode scanner. Decoding options and interface protocols can be tailored to a specific application.

Setup parameters are stored in non-volatile memory in the scanner and are retained even when power is off. Setup parameters change only when you reset them. You may need to hide adjacent code patches with your hand when scanning.

Program Set Up Flow

Scan "Set" to set up --> Scan selected barcode --> Scan "End" to confirm the setup.

User Preferences

Show Version


Scan this barcode to display firmware version.



Read device information

System Settings


Scan this barcode to return all parameters to the default values.



Set



Factory default settings




End

Customer's Factory Default


Scan barcodes below to set or delete customer's factory default.




Set



Save customer's factory default



Delete customer's factory default



End

Scan Mode


Scan a barcodes below to set the scanner to different modes.

Auto Scan Mode: In this mode, the scanner's illumination LED is turned off. Once an approaching object is detected, the scanner will turn on the illumination LED and start scanning.

Continue Scan Mode: The scanner always turns on its illumination LED for continuous operation without triggering.

Presentation Mode: Under this mode, the scanner keeps its illumination LED lighting on and continuously looks for any object approaching in. Once an approaching object is detected, the scanner starts scanning.

Kiosk Mode: In this mode, the scanner turns off the illumination LED and continuously looks for any object approaching in. Once an approaching object is detected, the scanner starts scanning, and the illumination LED will flash once if decoding complete.



Set




Auto Scan Mode (Default)




Continue Scan Mode



Presentation Mode




Kiosk Mode



End

Standby Time

Use the barcodes below to set the standby time for the applicable mode.



Set



15 seconds



1 minute




3 minutes




5 minutes (Default)




10 minutes



End



Set



15 minutes




20 minutes




25 minutes



30 minutes




Never



End

Same Code Delay Time for Continue Mode

Scan a barcode below to select the duration of the delay time for the applicable mode.



Set



300 msec



500 msec (Default)




1 sec



1.5 sec




2 sec




End

Decode Time

Set the time required for decoding.




Set




Short (Default)



Medium




Long



End

Customization Gain Level

Set gain level for captured image quality. When the light is low, the higher gain level can enhance the captured image quality for better scanning performance.



Set



Level 1 (Low)



Level 2




Level 3




Level 4 (Default)



Level 5



End



Set



Level 6



Level 7




Level 8



Level 9




Level 10



End

Motion Detect Sensibility for Auto Scan Mode & Presentation Mode

Set the motion detection sensibility level. The higher the level the more sensitive the condition becomes.



Set



Level 1 (High)




Level 2




Level 3




Level 4



Level 5 (Default)




End



Set



Level 6



Level 7




Level 8



Level 9




Level 10




End


Idle Wake Sensibility Level




Set




Level 1 (Low)




Level 2




Level 3




Level 4 (Default)



Level 5




End




Set



Level 6




Level 7




Level 8



Level 9




Level 10



End

Illumination LED Behavior

Set illumination behavior when device is in standby.




Set



Illumination LED Standby On



Illumination LED Standby Off
(Default)




End


- Illumination LED Standby On: LED on when in standby mode.
- Illumination LED Standby Off (Default): LED off when in standby mode.

Decoded Illumination LED Behavior for Kiosk Mode


Set illumination behavior when the device decodes successfully.




Set




High



Low
(Default)




Off




End

Decoded delay time for Auto Scan Mode


Set the delay time after a barcode has been read before scanning the next barcode.



Set




Disable (Default)




400 ms



800 ms




1.2 Sec




End

Mobile Phone Scan Support


Enable or disable mobile phone scan support.




Set



Enable




Disable (Default)



End

Power Up Beep On/ Off


Scan a barcode below to turn on/off power up beep.




Set



On (Default)



Off



End

Good Read Beep On/ Off

Scan a barcode below to turn on/off good read beep.



Set



On (Default)




Off




End

Good Read Beep Length

Scan a barcode below to select the duration of the beep signal after a good decode.



Set




10 msec



50 msec (Default)




100 msec



150 msec




200 msec




End

Interface Switch


Your 2D Imager supports interfaces such as USB HID, RS232 serial, and USB virtual COM. To switch the interface, simply select the appropriate cable and configure the proper interface by following interface selection.




Set




RS-232



USB Keyboard




USB Virtual COM Port
*Driver required




End


Terminal Character



Set




None




CR/LF

(V-COM & RS-232 Default)




CR


(HID Default)



TAB




LF




End

RS232 Baud Rate


Baud rate is the number of bits of data transmitted per second. Set the imager's baud rate to match the baud rate setting of the host device. Otherwise, data may not reach the host device or may reach it in distorted form.




Set




9600 (Default)




19200




38400




57600




End




Set



115200




230400




End

RS232 Parity Bit


Parity bit can be added to ensure the total number of the string is even or odd.




Set




None (Default)



Even parity



Odd parity




End

RS232 Stop Bit

Stop bit is used to signal the end of a transmission.



Set



1 Stop Bit (Default)




2 Stop Bit




End

RS232 Data Bit

Data bit sets the word length at 7 or 8 bits of data per character.




Set



CS7




CS8 (Default)



End

USB Speed

Scan a barcode below to set USB speed.



Set



USB 2.0




USB 1.1 (Default)




End

USB Output Speed for USB 1.1

Scan a barcode below to set USB 1.1 output speed.




Set




1 (Fastest)



2




3




4 (Default)




5



End



Set




6



7




8




9




10



End



Set




11




12



13




14



15




16 (Slowest)



End

Country Code


Scan the following settings to change the country code.



Set




US (Default)




Belgium




Britain




Denmark




End



Set



France




Germany




Italy




Norway




End




Set



Portugal




Spain




Sweden



Switzerland




End




Set




Japan



Hungary




Czech Republic



Slovakia




End



Serbia



Romania



Croatia




Poland




Finland




United Kingdom



Russia



End



Set




International Keyboard mode
(ALT mode)



Turkey-Q




Turkey-F



End

Persian/Arabic Language Encoding Support

Scan the following settings to change the encoding options.



Set




UTF-8 (Default)



ISO 8859-6



CP1256 (WINDOWS-1256)




End

Readable Symbologies

This section provides the programming barcodes for enabling and disabling readable symbologies. If the default values suit requirements, programming is not necessary.

All Symbologies



Set



Enable All




Default




1D Disable



2D Disable



End

UPC-A


Set



Enable UPC-A (Default)



Disable UPC-A



End


UPC-E




Set



Enable UPC-E



Disable UPC-E (Default)



End

EAN-8


Set



Enable EAN 8 (Default)



Disable EAN 8



End

EAN 13




Set



Enable EAN 13 (Default)




Disable EAN 13



End

JAN code for Books




Set



Enable



Disable (Default)



End

Code 128




Set




Enable Code 128 (Default)



Disable Code 128



End

Code 39


Set



Enable Code 39 (Default)



Disable Code 39



End

Code 93




Set



Enable Code 93 (Default)




Disable Code 93



End

Code 32




Set



Enable Code 32



Disable Code 32 (Default)




End

Code 11




Set



Enable Code 11



Disable Code 11 (Default)



End

Codabar




Set



Enable Codabar (Default)



Disable Codabar



End


Plessey




Set



Enable Plessey




Disable Plessey (Default)



End

MSI/Plessy




Set



Enable MSI/Plessy




Disable MSI/Plessy (Default)



End

Interleaved 2 of 5




Set



Enable Interleaved 2 of 5 (Default)




Disable Interleaved 2 of 5



End

IATA 2 of 5




Set



Enable IATA 2 of 5



Disable IATA 2 of 5 (Default)



End

Matrix 2 of 5




Set



Enable Matrix 2 of 5




Disable Matrix 2 of 5 (Default)



End

Straight 2 of 5




Set



Enable Straight 2 of 5




Disable Straight 2 of 5 (Default)




End

RSS 14 (GS1 DATABAR 14)




Set



Enable RSS 14 (GS1 DATABAR Expanded)
(Default)



Disable RSS 14 (GS1 DATABAR Expanded)




End

RSS Expanded (GS1 DATABAR Expanded)




Set



Enable RSS Expanded (GS1 DATABAR Expanded) (Default)




Disable RSS Expanded (GS1 DATABAR Expanded)



End

RSS Limited (GS1 DATABAR Limited)




Set



Enable RSS Limited (GS1 DATABAR Limited) (Default)




Disable RSS Limited (GS1 DATABAR Limited)



End

Component CC-A




Set



Enable Component CC-A



Disable Component CC-A (Default)



End

Component CC-B




Set



Enable Component CC-B




Disable Component CC-B (Default)



End

Component CC-C




Set



Enable Component CC-C



Disable Component CC-C (Default)



End

PDF417




Set




Enable PDF417 (Default)



Disable PDF417



End

Micro PDF417


Set



Enable Micro PDF417 (Default)



Disable Micro PDF417




End

Data Matrix




Set



Enable Data Matrix (Default)




Disable Data Matrix



End

QR Code




Set



Enable QR Code (Default)




Disable QR Code




End


Micro QR Code




Set



Enable Micro QR Code (Default)



Disable Micro QR Code



End

GS1-2D AIM ID

GS1 2D barcodes (GS1 DataMatrix, GS1 QR Code) output AIM ID Setting.




Set



Enable




Disable (Default)



End

GS1-128 AIM ID

GS1-128 output AIM ID Setting.




Set



Enable




Disable (Default)



End


GS1 DataBar Expanded Stacked




Set



Enable




Disable (Default)



End

GS1 DataBar 14 Stacked




Set



Enable




Disable (Default)



End

Aztec




Set



Enable Aztec




Disable Aztec (Default)



End

Pharmacode

(Pharmaceutical Binary Code)




Set



Enable Pharmacode



Disable Pharmacode (Default)



End

MaxiCode




Set



Enable MaxiCode



Disable MaxiCode (Default)




End

Symbology Features

This section provides the programming barcodes for selecting features available to different symbologies.

UPC / EAN




Set




Enable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8





Disable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8 (Default)




End

UPC-A


Set

Enable UPC-A Number System digit
(Default)


Disable UPC-A Number System digit




Enable UPC-A check digit (Default)




Disable UPC-A check digit




End




Set



Enable conversion of UPC-A to EAN13




Disable conversion of UPC-A to EAN13
(Default)



Enable Leading Character




Disable Leading Character (Default)



End

UPC-A Data Redundant Check



Set



Off (Default)




1



2




3




End


UPC-E




Set




Enable UPC-E Number System digit
(Default)




Disable UPC-E Number System digit




Enable UPC-E check digit (Default)




Disable UPC-E check digit




End




Set



Enable conversion of UPC-E to UPC-A




Disable conversion of UPC-E to UPC-A
(Default)




End


EAN 8




Set




Enable EAN 8 check digit (Default)




Disable EAN 8 check digit



Enable conversion of EAN 8 to EAN 13




Disable conversion of EAN 8 to EAN 13
(Default)



End

EAN 8 Data Redundant Check



Set



Off (Default)




1



2




3




End


EAN 13




Set




Enable EAN 13 check digit (Default)




Disable EAN 13 check digit




Enable conversion of EAN 13 to ISBN




Disable conversion of EAN 13 to ISBN
(Default)




End




Set




Enable conversion of EAN 13 to ISSN




Disable conversion of EAN 13 to ISSN
(Default)



First "0" can transmitted




First "0" can't transmitted(Default)



End

EAN 13 Data Redundant Check



Set



1



3



Off (Default)




2




End

JAN code for Books Separator



Set



[TAB] key x 2




[SPACE] key x 3




Others char Separator

For parameters requiring specific numeric values, scan the [PROGRAMMING GUIDE\ASCII Code] appropriately numbered barcode(s).




End



Set




None (Default)




End


Code 39




Set




Enable Code 39 full ASCII mode




Disable Code 39 full ASCII mode (Default)




Enable Start and Stop characters




Disable Start and Stop characters (Default)






End



Set



Disable Checksum (Default)

Enable checksum and send check
characterEnable checksum and strip check
character

End

Code 39 Data Redundant Check



Set



Off (Default)




1



2




3




End


Codabar




Set




Disable Checksum (Default)




Enable checksum and send check
character




Enable checksum and strip check
character




End




Set



Enable stripping Start and Stop characters
(Default)



Disable stripping Start and Stop characters



End

Codabar Redundant Check



Set



Off



1 (Default)



2




3




End

Code 93 Data Redundant Check




Set



Off (Default)




1



2



3



End

Code 128 Redundant Check



Set



Off



1 (Default)



2




3




End


Interleaved 2 of 5




Set




Disable Checksum (Default)




Enable checksum and send check character




Enable checksum and strip check character




End




Set



Default quiet zone checking
No length checking performed (Default)




Smaller quiet zone allowed



End

Interleaved 2 of 5 Data Redundant Check



Set



Off (Default)




1



2




3




End

MSI / Plessey


Set




Disable MSI Plessey checksum



Mod 10 checksum (Default)




Mod 10/10 checksum



Mod 11/10 checksum




End




Set



Strip checksum character(s)




Output checksum character(s) (Default)




End

Code 11


Set



Output checksum character(s)





Strip checksum character(s) (Default)



Disable checksum checking




Enable 1-digit checksum checking


Enable 2-digit checksum checking
(Default)

End


Data Matrix



Set




Enable mirror decoding (Default)




Disable mirror decoding




Enable rectangular Data Matrix decoding




Disable rectangular Data Matrix decoding
(Default)



End

QR / Micro QR

Set




Enable mirror decoding (Default)



Disable mirror decoding



End




Set



UTF8 conversion for word only



Universal UTF8 conversion (Default)



End

Note: Please install QR_UTF8_Conversion executable file before using this function.

Japanese Language Encoding Support




Set



Enable




Disable (Default)




End


Aztec




Set



Enable mirror decoding (Default)




Disable mirror decoding



End

FNC1 GS Substitution Values




Set



“Ctrl+]” (Default)




“Alt+29(KP)”
(nmvs)



End

Code 32 (Italian Pharmacode)



Set




Transmit


Alphabet "A" char



Disable Transmit
Alphabet "A" char
(Default)



End

PDF-417 Data Redundant Check

Set



Off (Default)




1



2




3




End


Matrix 2 of 5



Set




Disable Checksum (Default)




Enable checksum and send check character



Enable checksum and strip check character




End

Straight 2 of 5

Set



Disable Checksum (Default)

Enable checksum and send check
characterEnable checksum and strip check
character

End

Data Editing (Prefix)


Prefix is additional characters that can be sent before the scanned data. Please scan the barcodes in the selection below to set your prefix.

Prefix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan prefix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add "3" as prefix for all barcode type, then follow procedure as below, Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX. At the end, we scan [End] to completed setup.


All Prefix




Set



Enable All




Disable All (Default)




End


UPC / EAN Prefix




Set




Enable UPC-A




Disable UPC-A



Enable UPC-E




Disable UPC-E




End




Set




Enable EAN 8




Disable EAN 8



Enable EAN 13




Disable EAN 13




End


Code 128 Prefix




Set



Enable Code 128




Disable Code 128




End


Code 39 Prefix




Set



Enable Code 39




Disable Code 39




End


Code 93 Prefix




Set



Enable Code 93




Disable Code 93




End


Code 32 Prefix




Set



Enable Code 32



Disable Code 32




End


Code 11 Prefix




Set



Enable Code 11



Disable Code 11




End


Codabar Prefix




Set



Enable Codabar



Disable Codabar




End


Plessey Prefix




Set



Enable Plessey



Disable Plessey




End


MSI Prefix



Set



Enable MSI




Disable MSI




End


Interleaved 2 of 5 Prefix




Set



Enable Interleaved 2 of 5



Disable Interleaved 2 of 5




End


IATA 2 of 5 Prefix




Set



Enable IATA 2 of 5




Disable IATA 2 of 5




End


Matrix 2 of 5 Prefix




Set



Enable Matrix 2 of 5



Disable Matrix 2 of 5




End


Straight 2 of 5 Prefix




Set



Enable Straight 2 of 5




Disable Straight 2 of 5




End


RSS 14 Prefix (GS1 DATABAR 14 Prefix)




Set



Enable RSS 14 (GS1 DATABAR 14 Prefix)




Disable RSS 14 (GS1 DATABAR 14 Prefix)




End


RSS Expanded Prefix (GS1 DATABAR Expanded Prefix)




Set



Enable RSS Expanded (GS1 DATABAR
Expanded Prefix)




Disable RSS Expanded (GS1 DATABAR
Expanded Prefix)




End


RSS Limited Prefix (GS1 DATABAR Limited Prefix)




Set



Enable RSS Limited (GS1 DATABAR Limited Prefix)




Disable RSS Limited (GS1 DATABAR Limited Prefix)




End


Component CC-A Prefix




Set



Enable Component CC-A




Disable Component CC-A




End


Component CC-B Prefix




Set



Enable Component CC-B




Disable Component CC-B




End


Component CC-C Prefix



Set



Enable Component CC-C



Disable Component CC-C




End


PDF 417 Prefix




Set



Enable PDF 417



Disable PDF 417




End


Micro PDF 417 Prefix




Set



Enable Micro PDF 417




Disable Micro PDF 417




End


Data Matrix Prefix




Set



Enable Data Matrix




Disable Data Matrix




End


QR Prefix




Set



Enable QR Code




Disable QR Code




End


Micro QR Prefix




Set



Enable Micro QR




Disable Micro QR




End


Aztec Prefix



Set



Enable Aztec




Disable Aztec




End


MaxiCode Prefix




Set



Enable MaxiCode



Disable MaxiCode



End

Data Editing (Suffix)

Suffix is additional characters that can be sent after the scanned data. Please scan the barcodes in the selection below to set your suffix.

Suffix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan suffix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add "36" as suffix for all barcode type, then follow procedure as below. Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX and [6] as 6.


All Suffix




Set



Enable All




Disable All (Default)




End


UPC-A Suffix




Set



Enable UPC-A



Disable UPC-A




End


UPC-E Suffix




Set



Enable UPC-E



Disable UPC-E




End


EAN 8 Suffix



Set



Enable EAN 8



Disable EAN 8




End


EAN 13 Suffix



Set



Enable EAN 13




Disable EAN 13




End


Code 128 Suffix




Set



Enable Code 128




Disable Code 128




End


Code 39 Suffix




Set



Enable Code 39




Disable Code 39




End


Code 93 Suffix




Set



Enable Code 93




Disable Code 93




End


Code 32 Suffix




Set



Enable Code 32




Disable Code 32




End


Code 11 Suffix




Set



Enable Code 11



Disable Code 11




End


Codabar Suffix




Set



Enable Codabar



Disable Codabar




End


Plessey Suffix




Set



Enable Plessey




Disable Plessey




End


MSI Suffix




Set



Enable MSI




Disable MSI




End


Interleaved 2 of 5 Suffix



Set



Enable Interleaved 2 of 5




Disable Interleaved 2 of 5




End


IATA 2 of 5 Suffix




Set



Enable IATA 2 of 5



Disable IATA 2 of 5




End


Matrix 2 of 5 Suffix



Set



Enable Matrix 2 of 5




Disable Matrix 2 of 5




End

Straight 2 of 5 Suffix




Set




Enable Straight 2 of 5




Disable Straight 2 of 5




End

RSS 14 Suffix (GS1 DATABAR 14 Suffix)


Set



Enable RSS 14 (GS1 DATABAR 14 Suffix)




Disable RSS 14 (GS1 DATABAR 14 Suffix)




End


RSS Expanded Suffix (GS1 DATABAR Expanded Suffix)




Set




Enable RSS Expanded (GS1 DATABAR Expanded Suffix)






Disable RSS Expanded (GS1 DATABAR Expanded Suffix)



End

RSS Limited Suffix (GS1 DATABAR Limited Suffix)

Set


Enable RSS Limited (GS1 DATABAR Limited
Suffix)Disable RSS Limited (GS1 DATABAR
Limited Suffix)

End


Component CC-A Suffix




Set



Enable Component CC-A




Disable Component CC-A




End


Component CC-B Suffix



Set



Enable Component CC-B



Disable Component CC-B




End


Component CC-C Suffix




Set



Enable Component CC-C



Disable Component CC-C




End


PDF-417 Suffix



Set



Enable PDF417



Disable PDF417




End


Micro PDF-417 Suffix




Set



Enable Micro PDF417




Disable Micro PDF417




End


Data Matrix Suffix




Set



Data Matrix Enable



Data Matrix Disable




End


QR Code Suffix



Set



QR Code Enable



QR Code Disable




End


Micro QR Suffix




Set



Micro QR Enable




Micro QR Disable




End


Aztec Suffix




Set



Aztec Enable




Aztec Disable




End


MaxiCode Suffix



Set



MaxiCode Enable



MaxiCode Disable



End

Data Editing (Truncate/Return)


Truncate/Return Commands:

- Return the leftmost characters: Specify the number of leftmost characters you want returned.
- Truncate the leftmost characters: Specify the number of leftmost characters you want deleted.
- Return the Rightmost characters: Specify the number of rightmost characters you want returned.
- Truncate the Rightmost characters: Specify the number of rightmost characters you want deleted.
- Return the Middle characters: Returns the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends
- Truncate the Middle characters: Delete the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends

Suffix Set Up Flow

1. Scan Set.
2. Enable barcode type.
3. Scan one of Truncate/Return Command.
4. Select lengths using the numeric bar codes in ASCII Code Table.
5. Scan End.

Set All Symbologies Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable All (Default)



End

Set UPC-A Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set UPC-E Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set EAN-8 Truncate/Return

Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set EAN 13 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost




End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Code 128 Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Code 39 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Code 93 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Code 32 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Code 11 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Codabar Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Plessey Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)




End

Set MSI (Modified Plessey) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost




End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Interleaved 2 of 5 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Interleaved 2 of 5 (ITF).ReturnLeft.4



Enable



Disable (default)

Set IATA 2 of 5 Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost




End



Set



Return middle



Truncate middle




Disable (Default)



End

Set Matrix 2 of 5 Truncate/Return



Set




Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Straight 2 of 5 Truncate/Return



Set




Return leftmost



Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set RSS 14 (GS1 DataBar) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)




End


Set RSS Limited (GS1 DataBar Limited) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End


Set Component CC-A Truncate/Return



Set



Return leftmost



Truncate rightmost



Return rightmost



Truncate leftmost



End



Set



Return middle



Truncate middle




Disable (Default)




End

Set Component CC-B Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End


Set Component CC-C Truncate/Return



Set



Return leftmost



Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set PDF 417 Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost




End



Set



Return middle



Truncate middle



Disable (Default)



End

Set Micro PDF 417 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End


Set Data Martrix Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End

Set QR Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End


Set Micro QR Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End


Set Aztec Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End

Set MaxiCode Truncate/Return



Set




Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle



Disable (Default)



End

Code Settings

Set Lengths for Codes

- One Discrete Length

Select this option to decode the symbol containing a selected length.
Select the length using the numeric bar codes in ASCII Code Table.

Example 1:

To decode Interleaved 2 of 5 symbols with 8 characters:

- scan Set to set up
- scan Interleaved 2 of 5 One Discrete Length
- scan 8 in ASCII Code Table
- scan End to confirm the setup

Example 2:

To decode Interleaved 2 of 5 symbols with 12 characters:

- scan Set to set up
- scan Interleaved 2 of 5 One Discrete Length
- scan scan 1 followed by 2 in ASCII Code Table
- scan End to confirm the setup

- Two Discrete Lengths

Select this option to decode the symbol containing either of two selected lengths.
Select lengths using the numeric bar codes in ASCII Code Table.

Example:

To decode Code 128 symbols containing either 8 or 14 characters

- scan Set to set up
- scan Code 128 Two Discrete Length
- scan 0, 8, 1, and then 4 in ASCII Code Table
- scan End to confirm the setup

- Length Within Range

Select this option to decode the symbol with a specific length range. Select lengths using numeric bar codes in ASCII Code Table.

Example:

To decode Codabar symbols containing between 7 and 8 characters,

- a. scan Set to set up
- b. scan Codabar Length Within Range
- c. scan 0, 7, 0, and then 8 in ASCII Code Table
- d. scan End to confirm the setup

- Any Length

Select this option to decode the symbol containing any number of characters within the digital scanner's capability.

Example:

- a. scan Set to set up
- b. scan Matrix 2 of 5 Any Length
- c. scan End to confirm the setup

Set Lengths for Code 128




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 39




Set




One Discrete Length




Two Discrete Lengths



Length Within Range



Any Length (Default)



End

Set Lengths for Code 93



Set




One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End


Set Lengths for Codabar



Set



One Discrete Length




Two Discrete Lengths



Length Within Range



Any Length (Default)



End

Set Lengths for Interleaved 2 of 5




Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 11



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End

Set Lengths for MSI



Set



One Discrete Length



Two Discrete Lengths



Length Within Range




Any Length (Default)



End


Set Lengths for Matrix 2 of 5



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Code Identifiers

Scan the following barcodes to set symbology Identifiers.




Set




Disable Code ID (Default)



Enable factory standard ID



Enable AIM ID




End

Code Identifiers Table


Symbology	Factory Standard	AIM
UPC-A	A]E
UPC-E	E]E
EAN 8	FF]E
EAN 13	F]E
Code 128	K]C
Code 39	M]A
Code 93	L]G
Code 32	M]X
Code 11	O]H
Codabar	N]F
Plessey	P]P
MSI / Plessey	a]M
Interleaved 2 of 5	l]l
IATA 2 of 5	Z]R
Matrix 2 of 5	G]X
Straight 2 of 5	S]S
Pharmacode	H]X
RSS 14 (GS1 DATABAR 14)	RS]e
RSS Expanded (GS1 DataBar Expanded)	RX]e
RSS Limited (GS1 DataBar Limited)	RL]e
Component CC-A	m]e
Component CC-B	n]e
Component CC-C	i]e
PDF417	r]L
Micro PDF417	s]L
Data Matrix	t]d
QR	u]Q
Micro QR	j]Q
Aztec	e]z
MaxiCode	v]U
RSS 14	RS]e
RSS Expanded	RX]e

USB Keyboard FN 1 Substitution

This option applies only to the USB HID Keyboard Emulation device.




Set



Ctrl+] (Default)



Alt+29(KP)




End

Keyboard Caps Lock State

Scan a barcode below to turn Caps on or off.




Set




Caps Lock Off (Default)



Caps Lock On



End




Set



Alphabet always upper case



Alphabet always Lower case



Override



End

Function Key Mapping


Scan the following barcodes to enable or disable Function Key Mapping.




Set



Disable Function Key Mapping (Default)



Enable Function Key Mapping




End

Function Key Extended


Scan the following barcodes to enable or disable Function Key Extended. Enable Function Key Extended change the Function Key from [Left-CTRL] to [Right-CTRL].




Set



Disable Function Key Extended (Default)



Enable Function Key Extended




End

ASCII Code


For parameters requiring specific numeric values, scan the appropriately numbered barcode(s).




Space




!




"




#




\$




%




&




!




(




)




*




+




,




.




:




-




/




;




<




>




@




=




?




[




\




]




^




-




/




{




|




}




~




0




2




4




1




3




5




6




7



8




9




A

(Function Key
Mapping: Ctrl+a)



B


(Function Key
Mapping: Ctrl+b)




C
(Function Key
Mapping: Ctrl+c)




D
(Function Key
Mapping: Ctrl+d)




E
(Function Key
Mapping: Ctrl+e)



F
(Function Key
Mapping: Ctrl+f)




G
(Function Key
Mapping: Ctrl+g)




H

(Function Key Mapping: Ctrl+h)




I

(Function Key Mapping: Ctrl+i)




J

(Function Key Mapping: Ctrl+j)




K

(Function Key Mapping: Ctrl+k)




L


(Function Key Mapping: Ctrl+l)




M
(Function Key
Mapping: Ctrl+m)




N
(Function Key
Mapping: Ctrl+n)




O
(Function Key
Mapping: Ctrl+o)



P
(Function Key
Mapping: Ctrl+p)




Q
(Function Key
Mapping: Ctrl+q)




S

(Function Key Mapping: Ctrl+s)




R

(Function Key Mapping: Ctrl+r)




T

(Function Key Mapping: Ctrl+t)




U

(Function Key Mapping: Ctrl+u)




V


(Function Key Mapping: Ctrl+v)




W
(Function Key
Mapping: Ctrl+w)




X
(Function Key
Mapping: Ctrl+x)




Y
(Function Key
Mapping: Ctrl+y)




Z
(Function Key
Mapping: Ctrl+z)




a




b




c




d




e




f




g




h




i




j




k



l




m




o




q




n




p




r




s




t




u




v




w



x



y



z



Insert



Delete




Home



End



Up arrow



Down arrow



Left arrow



Right arrow




Tab




Backspace



Shift



ESC




Page up



Page down



Ctrl




Alt




F1




F2



F9



F10




F11



F12


ASCII Character Set for Serial Hosts




SOH




STX




ETX




EOT



ENQ




ACK



BELL



LF




VT



FF



CR



SO




SI


USB Virtual COM Driver Installing

If you use virtual COM port emulation, follow the steps below to start using the scanner.


1. Execute the driver (ZEBEX VCOM Driver Installation.exe).
2. Connect the scanner USB cable to the host computer.
3. Set the interface to USB Virtual COM Port.



Set



USB Virtual COM Port
*Driver required



End

4. On the computer, check Device Manager to see if the computer successfully detects the scanner as “Barcode Scanner USB-COM device.” (The COM port number would vary depending on different hardware environment).




JavaPOS Setting

This section provides the programming barcodes for setting JavaPOS and the flow of installing JavaPOS driver.

JavaPOS

Scan the following barcodes to enable or disable JavaPOS.




Set



JPOS Enable



JPOS Disable (Default)



End

JavaPOS Version

Our JavaPOS driver now is compatible with JavaPOS1.7.

Install the Java2 Runtime Environment

The JRE is Java's virtual machine that allows for applications to run on the host computer. To be able to run the JavaPOS application, you need a 1.7 version JRE. Ignore the following steps if you already have a JavaPOS1.7 or a later version in your host computer.

- Go to <http://java.sun.com>, and select this version of Java Runtime Environment.
- Install the program following the instructions.

Install the Service Object and JavaPOS files

In the "\Driver" folder, there are two files: ZbtJavapos.jar and jpos.xml. Please include ZbtJavapos.jar at your CLASSPATH and also copy the related "JPosEntry" option from the jpos.xml to your application's jpos.xml.

How to use RS232 scanner with JavaPOS Driver

Install the Java RXTXcomm API


In the \RXTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RXTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32.
2. Copy RXTXcomm.jar to your <JRE Install Folder>\lib directory.


Use barcodes to configure the scanner

JavaPOS configuration barcodes:


Set



RS-232



JPOS Enable



End



Running the JavaPOS Test utility

Please run the test application POStest.sh to evaluate your installation.

How to use JavaPOS driver at your application

1. Add “ZbtJavaPos.jar” from the “\Driver” folder to the CLASSPATH and copy the related “JPosEntry” option from the “jpos.xml”.
2. Modify the jpos.xml based on your COM Port
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
        "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

    <JposEntry logicalName="Z3172P">
        <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
        <vendor name="" url=""/>
        <jpos category="Scanner" version="1.7"/>
        <product description="Scanners" name="Scanner" url=""/>

        <!--Other non JavaPOS required property (mostly vendor properties and bus specific
properties i.e. RS232)-->
        <prop name="deviceType" type="String" value="2D"/>
        <prop name="deviceBus" type="String" value="RS232"/>
        <prop name="baudRate" type="String" value="9600"/>
        <prop name="parity" type="String" value="None"/>
        <prop name="portName" type="String" value="COM1"/>
        <prop name="flowControl" type="String" value="None"/>
        <prop name="stopBits" type="String" value="1"/>
        <prop name="dataBits" type="String" value="8"/>
    </JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
        "jpos/res/jcl.dtd">
<JposEntries>

</JposEntries>
```

Note: The default baud rate : 2D scanner =9600


How to use USB scanner with JavaPOS Driver

Configuring the Scanner via barcodes:

- Scan the barcodes in the sequence below to configure the scanner to usb-serial mode.

JavaPOS configuration bar codes:

Set




USB Virtual COM Port



JPOS Enable



End



Install the Java RTXcomm API

In the \RTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32
2. Copy RTXcomm.jar to your <JRE Install Folder>\lib directory.

Running the JavaPOS Test utility

Please run the test application to evaluate your installation.

How to Use JavaPOS Driver at your application

1. In the “\Driver” folder, copy “ZbtJavaPos.jar” and “jpos.xml” to your work folder.
2. Modify the jpos.xml .
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
    "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

    <JposEntry logicalName="Z3172P">
        <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
        <vendor name="" url=""/>
        <jpos category="Scanner" version="1.7"/>
        <product description="Scanners" name="Scanner" url=""/>

        <!--Other non JavaPOS required property (mostly vendor properties and bus specific properties i.e.
RS232)-->
            <prop name="deviceType" type="String" value="2D"/>
            <prop name="deviceBus" type="String" value="RS232"/>
            <prop name="baudRate" type="String" value="115200"/>
            <prop name="parity" type="String" value="None"/>
            <prop name="portName" type="String" value="COM56"/>
            <prop name="flowControl" type="String" value="None"/>
            <prop name="stopBits" type="String" value="1"/>
            <prop name="dataBits" type="String" value="8"/>
    </JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
    "jpos/res/jcl.dtd">
<JposEntries>
</JposEntries>
```